

5x7/5x9 12' Tower- Bushlan Outfitter Blind



Included
 (½"x1 ¼") 16-Nuts Bolts
 Tower
 (9/16"x2") 2-Staircase Bolts

Tools Needed
 (¾", 7/8", 13/16")Wrench
 (¾") Socket
 Cordless Drill

Instructions

- Raise Blind
 - Stub legs (with feet) to all 4 corners and put bolts in and loosely tighten nut
 - Attach "cross braces" to top of each outside leg on the top hole and loosely bolt. Allow them to hang as you continue. (See chart for measurements)
 - Attach the "brace ring" around the bottom of blind and loosely bolt (See chart for measurements)
 - Attach staircase. With staircase bolts
 - Tighten all bolts.
 - Recommendation-Tie down kit.
- Tips: Start from door when attaching metal (legs then braces)

Blind Size	Brace Ring (long and short side)	Cross Brace (long and short side)
5x7 12"	115" and 84"	153 ¼" and 137 ½"
5x9 12'	142 ½" and 84 ½"	169 ¾" and 137 1/8"